





**KUTLU
TRUCK**


CATALOGUE


**FIFTH WHEEL
&
CONTAINER SPARE PARTS**


BEŞİNCİ TEKER FIFTH WHEEL





Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" AYAKSIZ</p> <p>(EN) Fifth Wheel 2" (Only Casting)</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>		<p>901-1000 013-213</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" MN/TİPİ AYAKLI H150</p> <p>(EN) Fifth Wheel 2" H150</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK37C JSK 37 C JSK 37C JSK37 C JSK 37 C150 ZJ JSK37C150ZJ</p>	<p>901-1001 013-213-1S1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: h150	
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" MN/TİPİ AYAKLI H185</p> <p>(EN) Fifth Wheel 2" H185</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK37C JSK 37 C JSK 37C JSK37 C JSK 37 C185 ZJ JSK37C185ZJ</p>	<p>901-1002 013-213-1S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: h185	
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" MN/TİPİ AYAKLI H210</p> <p>(EN) Fifth Wheel 2" H220</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK37C JSK 37 C JSK 37C JSK37 C</p>	<p>901-1003 013-213-1S3</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: h220	
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" MN/TİPİ AYAKLI H250</p> <p>(EN) Fifth Wheel 2" H250</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK37C JSK 37 C JSK 37C JSK37 C JSK 37 C250 ZJ JSK37C- 250ZJ</p>	<p>901-1004 013-213-1S4</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: h250	
JOST	<p>(TR) PLEYT (Beşinci Teker) 2" MN/TİPİ AYAKLI H300</p> <p>(EN) Fifth Wheel 2" H300</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK37C JSK 37 C JSK 37C JSK37 C JSK 37 C300 ZJ JSK37C300ZJ</p>	<p>901-1005 013-213-1S5</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: h300	


Model	Description		901-2000 013-237
JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI BORULU TİP H190 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 		
Beşinci Teker / Fifth Wheel		DIMENSION: h190	

JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H135 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 		901-2001 013-238	
Beşinci Teker / Fifth Wheel		DIMENSION: h135		

JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H150 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	SK 2104-02 SK2104-02 SK210402	901-2002 013-234	
Beşinci Teker / Fifth Wheel		DIMENSION: h150		

JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H185 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	SK 2104-01 SK2104-01 SK210401	901-2003 013-233	
Beşinci Teker / Fifth Wheel		DIMENSION: h185		

JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H210 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 		901-2004 013-232	
Beşinci Teker / Fifth Wheel		DIMENSION: h210		

JOST	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H250 EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	SK 2104-14 SK2104-14 SK210414	901-2005 013-231	
Beşinci Teker / Fifth Wheel		DIMENSION: h250		

Model

JOST

Description

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 30mm DÜZ TİP
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2010

013-249



Beşinci Teker / Fifth Wheel

DIMENSION: h30

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 40mm DÜZ TİP
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2011

013-242



Beşinci Teker / Fifth Wheel

DIMENSION: h40

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 50mm DÜZ TİP
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2012

013-241



Beşinci Teker / Fifth Wheel

DIMENSION: h50

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 30mm
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2013

013-255



Beşinci Teker / Fifth Wheel

DIMENSION: h30

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 40mm
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2014

013-254



Beşinci Teker / Fifth Wheel

DIMENSION: h40

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTMESİ 50mm
- EN Raising Wedge, Fifth Wheel
- DE Keil, Sattelkupplung
- FR Partie, 5e roue
- ES Parte, 5ª Rueda
- PT Parte, 5ª roda
- RU часть, Опорно-сцепное устройство

Notes

Kit: 2 Pcs

901-2015

013-253



Beşinci Teker / Fifth Wheel

DIMENSION: h50

Model	Description		
JOST	<p>TR PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 2"</p> <p>EN Lock Jaw, Fifth Wheel</p> <p>DE Schloß Kinn, Sattelkupplung</p> <p>FR Partie, 5e roue</p> <p>ES Gancho</p> <p>PT Cloqueio Jaw, Roda quinta</p> <p>RU Блокировка зажима, Сцепное устройство</p>	SK 1489 SK1489 SK1489 SK 1489	<p>901-3000 013-275-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST DAF	<p>TR PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) CIRT KELEPÇESİ</p> <p>EN Tie Wrap</p> <p>DE Kabelbinder</p> <p>FR Partie, 5e roue</p> <p>ES Parte, 5ª Rueda</p> <p>PT Parte, 5ª roda</p> <p>RU Пластиковый Хомут-Стяжка</p>	SK 3121-13 SK3121-13 SK312113 1623196 109.202	<p>901-3001 013-213-11</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 142mm	
JOST	<p>TR PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 2" PİMİ (Ø20)</p> <p>EN Bolt For Lock</p> <p>DE Bolzen Für Verschlussshaken</p> <p>FR Partie, 5e roue</p> <p>ES Pasador Eje De Gancho</p> <p>PT Pino do eixo do gancho</p> <p>RU Фиксирующий штифт</p>	SK 2106-67 SK2106-67 SK210667	<p>901-3002 013-213-6</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø47x65	
DAF JOST FONTAINE	<p>TR PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) YAYI (Ø18)</p> <p>EN Spring</p> <p>DE Feder</p> <p>FR Partie, 5e roue</p> <p>ES Muelle Traccion</p> <p>PT Mola</p> <p>RU Пружина</p>	SK 847 SK847 SK847 0709389 CDSR236	<p>901-3003 013-289-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: Ø18x79.5	
JOST	<p>TR PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) SABİTLEME PİMİ</p> <p>EN Bolt, Spring</p> <p>DE Befestigungsstift</p> <p>FR Partie, 5e roue</p> <p>ES Pasador Eje De Gancho</p> <p>PT Pino do eixo do gancho</p> <p>RU Фиксирующий штифт</p>	SK 2122-04 SK2122-04 SK212204	<p>901-3004 013-213-10</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST RVI DAF VOLVO	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI 2" (3 Delik-Civatasız)</p> <p>EN Lock Jaw, Fifth Wheel</p> <p>DE Schloß Kinn, Sattelkupplung</p> <p>FR Partie, 5e roue</p> <p>ES Anillo Desgaste</p> <p>PT Cloqueio Jaw, Roda quinta</p> <p>RU Блокировка зажима, Сцепное устройство</p>	SK 2105-19 SK2105-19 SK210519 118022	<p>901-3005 013-276-Z</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø75	

Model	Description	
DAF JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CIVATASI M14x2x22mm</p> <p>(EN) Socket Head Bolt</p> <p>(DE) Inbusbolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo De Fijación Anillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	<p>SK 2121-07</p> <p>SK2121-07</p> <p>SK212107</p> <p>SK2121 07</p> <p>0834151</p> <p>662133601</p>
Notes Kit: 3 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M14x2x22

901-3006
013-276-1



JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI</p> <p>(EN) Locking Bar, Fifth Wheel</p> <p>(DE) Schloß Keil, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pestillo Cierre</p> <p>(PT) Cunha de travamento, Roda quinta</p> <p>(RU) Стопорный болт, Сцепное устройство</p>	<p>SK 3205-06</p> <p>SK3205-06</p> <p>SK320506</p> <p>0836790</p>
Notes Not Kit		
Beşinci Teker / Fifth Wheel		DIMENSION: ø20x23x4,5

901-3007
013-261



JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI SABİTLEME CIVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Befestigungsschraube</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	<p>SK 3221-01</p> <p>SK3221-01</p> <p>102.220</p>
Notes Not Kit		
Beşinci Teker / Fifth Wheel		DIMENSION: M20x2,5x95

901-3008
013-521-1



JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI SABİTLEME CIVATA SOMUNU</p> <p>(EN) Castle Nut</p> <p>(DE) Befestigungsschraube Mutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca</p> <p>(PT) Porca</p> <p>(RU) Гайка</p>	<p>SK 3221-01</p> <p>SKS3221-01S</p> <p>104.220</p>
Notes Not Kit		
Beşinci Teker / Fifth Wheel		DIMENSION: M20x2,5

901-3009
013-521-2



JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI SABİTLEME CIVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	<p>SK 3221-01</p> <p>SKS3221-01S</p> <p>105.169</p>
Notes Not Kit		
Beşinci Teker / Fifth Wheel		DIMENSION: ø21xø36,50



901-3010
013-521-3










JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI SABİTLEME CIVATA KİLİT PİM</p> <p>(EN) Split Pin</p> <p>(DE) Splint</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Grapilla</p> <p>(PT) Cupilha Partes</p> <p>(RU) Части шплинт</p>	<p>103001</p>
Notes Not Kit		
Beşinci Teker / Fifth Wheel		DIMENSION: ø4x36


901-3011
013-521-4





Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ SAĞ</p> <p>(EN) Thrust Plate</p> <p>(DE) Gleitscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Segmentos Nylon</p> <p>(PT) Segmentos de nylon</p> <p>(RU) Пластина</p>	SK 3105-129R SK3105-129R SK3105129RS	<p>901-3012 013-800-R1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2" / RIGHT / SAĞ	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ SOL</p> <p>(EN) Thrust Plate</p> <p>(DE) Gleitscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Segmentos Nylon</p> <p>(PT) Segmentos de nylon</p> <p>(RU) Пластина</p>	SK 3105-129L SKS3105-129L SKS3105129LS	<p>901-3013 013-800-L1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2" / LEFT / SOL	
JOST DAF VOLVO	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ 2" (ALT)</p> <p>(EN) Mounting, Fifth Wheel</p> <p>(DE) Lager, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda</p> <p>(PT) Bomba sist. arrefecimento, Roda quinta</p> <p>(RU) Упруго-демпф. элемент, Сцепное у-во</p>	SK 2105-25 SK210525 SK2105-25 0834154 1518225	<p>901-3014 013-284-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 105x115x16	
JOST DAF VOLVO	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ 2" (ÜST)</p> <p>(EN) Mounting, Fifth Wheel</p> <p>(DE) Lager, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda</p> <p>(PT) Bomba sist. arrefecimento, Roda quinta</p> <p>(RU) Упруго-демпф. элемент, Сцепное у-во</p>	SK 1259 SK1259 SK1259 0834153 1518224	<p>901-3015 013-284-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 161x177x65	
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME KEPİ</p> <p>(EN) Bracket</p> <p>(DE) Platte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Placa</p> <p>(PT) Plaqueta</p> <p>(RU) Пластина</p>	SK 1372 SK1372 SK1372	<p>901-3016 013-291</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
DAF VOLVO JOST	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ BAĞLANTI CIVATASI</p> <p>(EN) Bolt, Fifth Wheel</p> <p>(DE) Schraube</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda, Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	102213	<p>901-3017 013-290-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2x110	


Model	Description		
DAF VOLVO JOST	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ BAĞLANTI CİVATA SOMUNU</p> <p>(EN) Lock Nut</p> <p>(DE) Sicherungsmutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda, Tuerca</p> <p>(PT) Porca</p> <p>(RU) Самоконтрящаяся гайка</p>	104.112	<p>901-3018 013-290-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2	
DAF VOLVO JOST	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ BAĞLANTI CİVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda, Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	105.183	<p>901-3019 013-290-3</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø17xø30	
DAF VOLVO JOST	<p>(TR) PLEYT (Beşinci Teker) KARABİNALI ZİNCİR</p> <p>(EN) Spring Hook, Chain</p> <p>(DE) Karabinerhaken</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) Весна крюк, цепи и клин</p>	SK1436V SK1436 V SK 1436 V SK 1436 SK1436 119.041	<p>901-3020 013-212-7</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ BORULU TİP</p> <p>(EN) Rubber Bearing</p> <p>(DE) Gummibüchse</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bujes Para Quinta Rueda</p> <p>(PT) Bucha de borracha</p> <p>(RU) резиновый Резиновая</p>	SK 2905-94 SK2905-94 SK290594	<p>901-3021 013-288-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAKOZ BORULU TİP</p> <p>(EN) Plastic Bearing</p> <p>(DE) Kunststofflager</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Kit De Reparación, Barra Del Eje</p> <p>(PT) Jogo de reparo, Haste do eixo</p> <p>(RU) пластмас Подшипник</p>	SK 3105-95 SK3105-95 SK310595	<p>901-3022 013-288-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) SABİTLEME PERNOSU BORULU TİP</p> <p>(EN) Pivot Pin</p> <p>(DE) Lagerbolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Barra Del Eje</p> <p>(PT) Barra do Eixo</p> <p>(RU) Монтажные части</p>	SK 3104-05 SK3104-05 SK310405	<p>901-3023 013-295</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø50x156	


Model	Description		901-3024 013-295-2
JOST	<p>(TR) PLEYT (Beşinci Teker) PERNO SABİTLEME CİVATASI BORULU TİP</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda, Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 3121-071 SK3121-071 SK3121071S	
Beşinci Teker / Fifth Wheel		DIMENSION: M12x1,75x2	

Model	Description		901-3025 013-295-3
JOST	<p>(TR) PLEYT (Beşinci Teker) PERNO SABİTLEME CİVATA PULU BORULU TİP</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda, Tornillo</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 3121-071 SK3121-071 SK3121071S	
Beşinci Teker / Fifth Wheel		DIMENSION: ø50xø13x33	

Model	Description		901-3026 013-213-2
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAR CİVATASI</p> <p>(EN) Adjusting Screw</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 3105-150 SK3105-150 SK3105150	
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2x415	

Model	Description		901-3027 013-213-2S
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAR CİVATA SOMUNU</p> <p>(EN) Nut</p> <p>(DE) Mutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca Hexagonal</p> <p>(PT) Porca</p> <p>(RU) Гайка</p>	104.148/1	
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2	

Model	Description		901-3028 013-213-2S1
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAR CİVATASI SOMUNU ÖZEL KARE</p> <p>(EN) Special Nut</p> <p>(DE) Mutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca Hexagonal</p> <p>(PT) Porca</p> <p>(RU) Гайка</p>	SK 3205-07 SK3205-07 SK320507 104.457	
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2	

Model	Description		901-3029 013-213-4
JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU</p> <p>(EN) Handle</p> <p>(DE) Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla</p> <p>(PT) Maçaneta</p> <p>(RU) Рукоятка</p>	SK 3105-15 SK3105-15 SK310515 119.235	
Beşinci Teker / Fifth Wheel		DIMENSION: x	

Model	Description	
JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL SABİTLEME CİVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Bolzen, Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo, Perilla</p> <p>(PT) Parafuso, Maçaneta</p> <p>(RU) Болт, Рукоятка</p>	<p>SK 1513</p> <p>SKS1513</p> <p>SKS 71513</p> <p>SKS71513S</p> <p>0834148S</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2x40

901-3030
013-522-2



JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL SABİTLEME CİVATA SOMUNU</p> <p>(EN) Castle Nut</p> <p>(DE) Mutter, Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca, Perilla</p> <p>(PT) Porca, Maçaneta</p> <p>(RU) Гайка, Шайба</p>	<p>SK 1513</p> <p>SKS1513</p> <p>SKS 71513</p> <p>SKS71513S</p> <p>0834148S</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2

901-3031
013-522-3



JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU UZATMASI</p> <p>(EN) Handle</p> <p>(DE) Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla</p> <p>(PT) Maçaneta</p> <p>(RU) Рукоятка</p>	<p>SK 3105-113</p> <p>SK3105-113</p> <p>SK3105113</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 356x116

901-3032
013-213-4S



JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU UZATMA CİVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Bolzen, Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla, Tornillo</p> <p>(PT) Parafuso, Maçaneta</p> <p>(RU) Болт, Рукоятка</p>	<p>102.223</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1,5x35mm

901-3033
013-213-4S1



JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTISI</p> <p>(EN) Lock Plate / Latch</p> <p>(DE) Sicherungsblech</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela De Seguridad</p> <p>(PT) Arruela de segurança</p> <p>(RU) Стопорная шайба</p>	<p>SK 3121-52</p> <p>SK3121-52</p> <p>SK312152</p> <p>2011455</p> <p>119.234</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: x







901-3034
013-213-14














JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTI CİVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Sechskantschraube</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela De Seguridad, Tornillo</p> <p>(PT) Parafuso, Maçaneta</p> <p>(RU) Болт, Рукоятка</p>	<p>102.570</p>
Notes		
Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1,5x70







901-3035
013-213-13S1








Model	Description		
JOST DAF	<p>TR PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTI CİVATA SOMUNU</p> <p>EN Lock Nut</p> <p>DE Sicherungsmutter</p> <p>FR Partie, 5e roue</p> <p>ES Arandela De Seguridad, Tuerca</p> <p>PT Porca, Maçaneta</p> <p>RU Шайба, Рукоятка</p>	104.107	<p>901-3036 013-213-13S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5	
JOST DAF	<p>TR PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTI CİVATA PULU</p> <p>EN Washer</p> <p>DE Scheibe</p> <p>FR Partie, 5e roue</p> <p>ES Arandela De Seguridad, Arandela</p> <p>PT Arruela, Maçaneta</p> <p>RU Шайба, Шайба</p>	107.007	<p>901-3037 013-213-13S3</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø10.5xø20	
JOST DAF	<p>TR PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTI BURCU</p> <p>EN Noose</p> <p>DE Abstandrohr</p> <p>FR Partie, 5e roue</p> <p>ES Tubo Espaciador</p> <p>PT Tubo espaçador</p> <p>RU Вставка Ресорная</p>	SK3121-59 SK 3121-59 SK312159 110.161	<p>901-3038 013-213-13S4</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>TR PLEYT (Beşinci Teker) ÇEKME KOL BAĞLANTI YAYI</p> <p>EN Spring</p> <p>DE Feder</p> <p>FR Partie, 5e roue</p> <p>ES Muelle, Arandela De Seguridad</p> <p>PT Mola, Maçaneta</p> <p>RU Пружина, Рукоятка</p>	117177	<p>901-3039 013-213-13S5</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>TR PLEYT (Beşinci Teker) ARA KOLU</p> <p>EN Lever</p> <p>DE Zuggriff</p> <p>FR Partie, 5e roue</p> <p>ES Perilla</p> <p>PT Maçaneta</p> <p>RU Рукоятка</p>	SK 3105-18 SK3105-18 SK310518 119.236	<p>901-3040 013-213-5</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>TR PLEYT (Beşinci Teker) EMNİYET YAYI</p> <p>EN Double Tension Spring</p> <p>DE Feder, Sattelkupplung</p> <p>FR Partie, 5e roue</p> <p>ES Muelle, La Quinta Rueda</p> <p>PT Mola</p> <p>RU Пружина, Опорно-цепное устройство</p>	SK 3105-20 SK3105-20 SK310520 0836794	<p>901-3041 013-289</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø47x144	

Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI M16x45mm</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 3110-009 SK3110-009 SK3110009S	<p>901-3042 013-213-7S</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x45	
JOST	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME CİVATASI M16x80mm</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>		<p>901-3043 013-213-8</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x80	
JOST	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME CİVATASI M16x100mm</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>		<p>901-3044 013-213-8S</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x100	
JOST	<p>(TR) PLEYT (Beşinci Teker) YAĞLAMA TAKIM TAPASI</p> <p>(EN) Plug</p> <p>(DE) Stopfen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tapón</p> <p>(PT) Bujão</p> <p>(RU) Заглушка</p>	013.012 4337200900 04337200900	<p>901-3045 013-213-3S</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø6.3	
JOST	<p>(TR) PLEYT (Beşinci Teker) YAĞLAMA TAPASI</p> <p>(EN) Plug</p> <p>(DE) Stopfen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tapón</p> <p>(PT) Bujão</p> <p>(RU) Заглушка</p>	000.010.021 000010021 000 010 021	<p>901-3046 013-213-3S1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 2" Çırtlı</p> <p>(EN) Lock Jaw, Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Gancho De Cierre</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	SK 1489 Z SK1489Z SK1489Z SK1489 Z	<p>901-4000 013-275-Z</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 2" Takım</p> <p>(EN) Lock Jaw, Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Gancho De Cierre</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	SK 3221-52 SK3221-52 SK322152 SK 3221 52	<p>901-4001 013-275</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST RVI DAF VOLVO	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI 2" CİVATALI (3 Delik)</p> <p>(EN) Lock Jaw, Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Anillo</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2121-51 SK2121-51 SK212151 SK2121 51 0882675 85101383	<p>901-4002 013-276</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
MAN DAF JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Segmentos Nylon</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3106-003 SK3106-003 SK3106003 1434610	<p>901-4003 013-800</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ SAĞ</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Segmentos Nylon</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3105-129R SK3105-129R SK3105129R	<p>901-4004 013-800-R</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: RIGHT / SAĞ	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ SOL</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Segmentos Nylon</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3105-129L SK3105-129L SK3105129L	<p>901-4005 013-800-L</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: LEFT / SOL	
JOST DAF VOLVO	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ 2" TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2105-25 SK 1259 SK2105 SK1259 SK2105 SK1259 0834154 0834153 1518225 1518224	<p>901-4006 013-284</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

Model	Description		
JOST DAF VOLVO	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI BORULU TİP</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>		<p>901-4007 013-288</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI CİVATASI TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3221-01 SK3221-01	<p>901-4008 013-521</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: M20x2,5x95
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KOL KİLİTLEME CİVATASI TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3521-03 SK3521-03 SK352103 2011456 096.535	<p>901-4009 013-213-13</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: M10x70
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL CİVATASI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 1513 SK1513 SK 71513 SK71513 0834148	<p>901-4010 013-522</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: M16x40
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) YEDEK PARÇA SABİTLEME CİVATASI TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-50 SK2421-50 SK242150 0834834 095.561	<p>901-4011 013-213-12</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: M16x35
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) YAĞLAMA TAKIMI</p> <p>(EN) Repair Kit, Lubricating Oil Line</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3108-02 SK3108-02 SK310802 2000674 119.038	<p>901-4012 013-213-3</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 533mm

Model	Description		
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Anillo</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3221-50 SK3221-50 SK322150 0837240	<p>901-4013 013-500</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" YAĞLAMALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Anillo</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3221-50 Z SK3221-50Z SK322150Z	<p>901-4014 013-514</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) TAMİR TAKIMI 2" YAĞLAMALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Gancho De Cierre</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3221-52 Z SK3221-52Z SK322152Z	<p>901-4015 013-514</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) TAMİR TAKIMI 2" YAĞLAMALI YAYSIZ-PİMSİZ</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Gancho De Cierre</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3108-05 SK3108-05 SK310805	<p>901-4016 013-515</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA TAMİR TAKIMI 2" YAĞLAMALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Anillo</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-072 Z SK3121-072Z SK3121072Z	<p>901-4017 013-517</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" CİVATALI HALATLI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparacion Anillo</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-50 SK3121-50 SK312150 0882682	<p>901-4018 013-506</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

Model	Description	
JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" ÇİVATALI - YAĞLAMALI - HALATLI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparacion Anillo</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 3121-50 Z SK3121-50Z SK312150Z
Notes Kit: 1/1/1/1/3/1/1/1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4019
013-507



JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" ÇİVATALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparacion Anillo</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 3121-51 SK3121-51 SK312151 0882683
Notes Kit: 1/1/1/1/3/1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4020
013-508



JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" ÇİVATALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparacion Anillo</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 3121-56 SK3121-56 SK312156
Notes Kit: 1/1/1/1/3/1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4021
013-509



JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2" ÇİVATALI - YAĞLAMALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparacion Anillo</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 3121-56 Z SK3121-56Z SK312156Z
Notes Kit: 1/1/1/1/3/1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4022
013-510



JOST	<p>TR PLEYT (Beşinci Teker) 4 DELİK AŞINMA AYI - KİLİT TAMİR TAKIMI 2" ÇİVATALI - YAĞLAMALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparacion Anillo</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 3121-60 Z SK3121-60Z SK312160Z
Notes Kit: 1/1/1/1/4/1/1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4023
013-511



JOST	<p>TR PLEYT (Beşinci Teker) KAUCUK TAMİR TAKIMI 2" SIKTIRMA ÇİVATALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2121-69 SK2121-69 SK212169
Notes Kit: 2/2/8 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

901-4024
013-516



Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) TAMİR TAKIMI 2" BORULU TİP - PERNOLU</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-58 SK3121-58 SK312158	<p>901-4025 013-518</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI 2" BORULU TİP - PERNOLU</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-61 SK3121-61 SK312161	<p>901-4026 013-519</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU TAKMİR TAKIMI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-063 SK3121-063 SK3121063	<p>901-4027 013-213-4S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
DAF VOLVO JOST	<p>(TR) PLEYT (Beşinci Teker) KAUCUK TAKOZ BAĞLANTI CİVATASI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2121-15 SK2121-15 SK212115 0834156 1697088	<p>901-4028 013-290</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x110	
JOST	<p>(TR) PLEYT (Beşinci Teker) PERNO SABİTLEME CİVATASI BORULU TİP</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-071 SK3121-071 SK3121071	<p>901-4029 013-295-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M12x18	
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI M16x45mm</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3110-009 SK3110-009 SK3110009	<p>901-4030 013-213-7</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M16x45	

Model

JOST

Description

- TR PLEYT (Beşinci Teker) YÜKSELTME CIVATASI M16x80mm
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes

Kit: 8 Pcs

901-4031

013-213-8S1



Beşinci Teker / Fifth Wheel

DIMENSION: M16x80

JOST

- TR PLEYT (Beşinci Teker) YÜKSELTME CIVATASI M16x100mm
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes

Kit: 8 Pcs

901-4032

013-213-8S2



Beşinci Teker / Fifth Wheel

DIMENSION: M16x100

JOST

- TR PLEYT (Beşinci Teker) AYAĞI H135
- EN Pedestal, Fifth Wheel
- DE Sockel, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Placa, La Quinta Ruedae, 5º Rueda
- PT Pedestal, Roda quinta
- RU Подрамник ОСУ, Опорно-сцепное устройство

Notes

Kit=2 Pcs



Beşinci Teker / Fifth Wheel

DIMENSION: H135

JOST

- TR PLEYT (Beşinci Teker) AYAĞI H150
- EN Pedestal, Fifth Wheel
- DE Sockel, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Placa, La Quinta Ruedae, 5º Rueda
- PT Pedestal, Roda quinta
- RU Подрамник ОСУ, Опорно-сцепное устройство

Notes

Kit=2 Pcs

SKE 001005620
SKE001005620**902-2001**

013-236



Beşinci Teker / Fifth Wheel

DIMENSION: H150

JOST

- TR PLEYT (Beşinci Teker) AYAĞI H185
- EN Pedestal, Fifth Wheel
- DE Sockel, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Placa, La Quinta Ruedae, 5º Rueda
- PT Pedestal, Roda quinta
- RU Подрамник ОСУ, Опорно-сцепное устройство

Notes

Kit=2 Pcs

SKE 001005720
SKE001005720**902-2002**

013-235



Beşinci Teker / Fifth Wheel

DIMENSION: H185

JOST

- TR PLEYT (Beşinci Teker) AYAĞI H225
- EN Pedestal, Fifth Wheel
- DE Sockel, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Placa, La Quinta Ruedae, 5º Rueda
- PT Pedestal, Roda quinta
- RU Подрамник ОСУ, Опорно-сцепное устройство

Notes

Kit=2 Pcs







SKE 001005820
SKE001005820**902-2003**


013-239-1





Beşinci Teker / Fifth Wheel


DIMENSION: H225


Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAĞI H250</p> <p>(EN) Pedestal, Fifth Wheel</p> <p>(DE) Sockel, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Placa, La Quinta Ruedae, 5ª Rueda</p> <p>(PT) Pedestal, Roda quinta</p> <p>(RU) Подрамник ОСУ, Опорно-сцепное устройство</p>	SKE 001005920 SKE001005920	<p>902-2004 013-239-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: H250	
JOST	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTMESİ 30mm DESENLI TIP</p> <p>(EN) Raising Wedge, Fifth Wheel</p> <p>(DE) Keil, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>		<p>902-2010 013-243</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: H30	
JOST	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTMESİ 40mm DESENLI TIP</p> <p>(EN) Raising Wedge, Fifth Wheel</p> <p>(DE) Keil, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>		<p>902-2011 013-244</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: H40	
JOST	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTMESİ 50mm DESENLI TIP</p> <p>(EN) Raising Wedge, Fifth Wheel</p> <p>(DE) Keil, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>		<p>902-2012 013-250</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: H50	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI 2" CİVATASIZ (4 Delik) TEK PARÇA DÖVME</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>		<p>902-3000 013-277-10</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI SACI 2" (4 Delik-Civatasız)</p> <p>(EN) Wearing Ring, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	SK 3105-93 SK3105-93 SK310593 118.021	<p>902-3001 013-278-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø94	


Model	Description		902-3002 013-278-2
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI PLASTİĞİ 2" (4 Delik İçin-Civatasız)</p> <p>(EN) Wearing Ring, Fifth Wheel</p> <p>(DE) Verschleissring</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Anillo De Desgaste</p> <p>(PT) Anel de desgaste</p> <p>(RU) Противознозное кольцо</p>	SK 3105-92 SK3105-92 SK310592 015.059	
Notes Not Kit			
Beşinci Teker / Fifth Wheel		DIMENSION: ø75xø94	


Model	Description		902-3003 013-277-1
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CIVATASI</p> <p>(EN) Socket Head Bolt</p> <p>(DE) Inbusbolzen</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Tornillo, Bloqueo Jaw</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 3121-55 SK3121-55 SK312155 102.217	
Notes Not Kit: 4 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M10x20	

Model	Description		902-3004 013-262
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI 2"</p> <p>(EN) Locking Bar, Fifth Wheel</p> <p>(DE) Schloß Keil, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Tornillo De Bloqueo, La Quinta Rueda</p> <p>(PT) Cunha de travamento, Roda quinta</p> <p>(RU) Стопорный болт, Сцепное устройство</p>	SK 0010-097 SK0010-097 SK0010097 118.031	
Notes Not Kit			
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2x234,50	

Model	Description		902-3005 013-262-1
JOST	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMA CIVATASI</p> <p>(EN) Special Bolt, Fifth Wheel</p> <p>(DE) Inbusbolzen</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	102.224	
Notes Not Kit			
Beşinci Teker / Fifth Wheel		DIMENSION: M16x2x18	

Model	Description		902-3006 013-214-1
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME KEPİ</p> <p>(EN) Bracket</p> <p>(DE) Abstandsteil</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Distance Piece</p> <p>(PT) Distance Piece</p> <p>(RU) Прокладка</p>	SKE 001530220 SKSE001530220	
Notes Not Kit: 2 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

Model	Description		902-3007 013-214-3S
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CIVATASI</p> <p>(EN) Special Bolt, Fifth Wheel</p> <p>(DE) Bolzen, Abstandsteil</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Tornillo, Distance Piece</p> <p>(PT) Parafuso</p> <p>(RU) Болт, Прокладка</p>	SKE 001011400 SKSE001011400S	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M20x2,5x80	

Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOL KİLİT YAYI</p> <p>(EN) Locking Spring, Fifth Wheel</p> <p>(DE) Feder, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Muelle, La Quinta Rueda</p> <p>(PT) Mola</p> <p>(RU) Пружина, Опорно-цепное устройство</p>	SKE 001440000 SKE001440000 1654675 095.071	<p>902-3008 013-213-13S6</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø16x105	
JOST	<p>(TR) PLEYT (Beşinci Teker) ARA KOL YAYI</p> <p>(EN) Lever Spring, Fifth Wheel</p> <p>(DE) Feder, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Muelle, La Quinta Rueda</p> <p>(PT) Mola</p> <p>(RU) Пружина, Опорно-цепное устройство</p>	SKE 001009800 SKE001009800 9507418 095.074	<p>902-3009 013-213-13S7</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø23.5x57	
JOST	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAKOZ</p> <p>(EN) Plastic Bearing, Fifth Wheel</p> <p>(DE) Kunststofflager</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit de reparación, Barra del eje</p> <p>(PT) Jogo de reparo, Haste do eixo</p> <p>(RU) пластмас Подшипник</p>	15061	<p>902-3010 013-285-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: ø126x135x117	
JOST	<p>(TR) PLEYT (Beşinci Teker) KAUÇUK TAKOZ</p> <p>(EN) Rubber Bearing, Fifth Wheel</p> <p>(DE) Kunststofflager</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Bujes Para Quinta Rueda</p> <p>(PT) Quinto cubo da roda</p> <p>(RU) пластмас Подшипник</p>	211.120/SD	<p>902-3011 013-285-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 78x40x29	
JOST	<p>(TR) PLEYT (Beşinci Teker) ÜST AŞINMA PLAKASI 4 DELİK</p> <p>(EN) Thrust Plate</p> <p>(DE) Gleitscheibe</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Segmentos Nylon</p> <p>(PT) Segmentos de nylon</p> <p>(RU) Пластина</p>	SK 0010-070 SK 0010070 SK0010-070 SK0010070 015.090	<p>902-3012 013-801-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST	<p>(TR) PLEYT (Beşinci Teker) ÜST AŞINMA PLAKA CIVATASI</p> <p>(EN) Bolt, Thrust Plate</p> <p>(DE) Bolzen, Gleitscheibe</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Tornillo, Segmentos Nylon</p> <p>(PT) Parafuso, Segmentos de nylon</p> <p>(RU) Болт, Пластина</p>	SK 3121-062 SKS3121062 SKS3121-062 SKS3121-062S 102.227	<p>902-3013 013-801-2S</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M12x1,75x125	

Model **Description**

JOST

TR PLEYT (Beşinci Teker) AŞINMA AYI 2" ÇİVATALI (4 Delik)TEK PARÇA DÖVME

EN Repair Kit, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel

DIMENSION: 2"

902-4000
013-277



Notes
Kit: 1/4 Pcs

JOST

TR PLEYT (Beşinci Teker) AŞINMA AYI PLASTİĞİ 2" ÇİVATALI TAKIM

EN Repair Kit, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel

DIMENSION: 2"

902-4001
013-592

SKE 001740020
SKE001740020
SKE001740020



Notes
Kit: 1/4 Pcs

JOST

TR PLEYT (Beşinci Teker) AŞINMA AYI 2" ÇİVATSIZ (4 Delik) SAÇLI PLASTİKLİ

EN Lock Jaw, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel

DIMENSION: 2"

902-4002
013-278-10



Notes
Kit: 1/1 Pcs

JOST

TR PLEYT (Beşinci Teker) AŞINMA AYI 2" ÇİVATALI (4 Delik) SAÇLI PLASTİKLİ

EN Repair Kit, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel

DIMENSION: 2"

902-4003
013-278

SK 3105-94
SK3105-94
SK310594



Notes
Kit: 1/1/4 Pcs

JOST

TR PLEYT (Beşinci Teker) KİLİTLEME KAMASI ÇİVATALI

EN Repair Kit, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel

DIMENSION: 2"

902-4004
013-588

SKE 001009720
SKE001009720
SKE001009720



Notes
Kit: 1/1 Pcs

JOST

TR PLEYT (Beşinci Teker) AYAK SABİTLEME ÇİVATA TAKIMI

EN Special Bolt, Repair Kit, Fifth Wheel

DE Reparatursatz, Sattelkupplung

FR Kit de Réparation, 5e roue

ES Kit Reparación Anillo 5º

PT Jogo de reparo, Roda quinta

RU Ремонтный комплект, Сцепное устройство

Beşinci Teker / Fifth Wheel







DIMENSION: M20x2,5x80

902-4005
013-214-3

SKE 001011400
SKE001011400



Notes
Kit:4 Pcs

Model	Description		
JOST	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>		<p>902-4006 013-285</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI CİVATALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	<p>SKE 001370220</p> <p>SKE001370220</p> <p>SKE001370220</p>	<p>902-4007 013-590</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI CİVATALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	<p>SKE 001370020</p> <p>SKE001370020</p> <p>SKE001370020</p>	<p>902-4008 013-593</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİK CİVATALI TAKIM</p> <p>(EN) Special Bolt, Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>		<p>902-4009 013-801-2</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ CİVATALI TAKIM</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	<p>SKE 001007020</p> <p>SKE001007020</p> <p>SKE001007020</p>	<p>902-4010 013-801</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
JOST	<p>(TR) PLEYT (Beşinci Teker) AYAR CİVATALI TAKIMI</p> <p>(EN) Adjusting Screw With Guide</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	<p>SKE 500740220</p> <p>SKE500740220</p> <p>SKE500740220</p>	<p>902-4011 013-214-2</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"

Model	Description	
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA-YAĞLAMA-PİM TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	<p>SKE 001640020</p> <p>SKE001640020</p> <p>SKE001640020</p>
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4012
013-591



JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4013
013-540



JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4014
013-541



JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA-YAĞLAMA-PLASTİK TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4015
013-542



JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA-PLASTİK TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4016
013-543



JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-SABİTLEME KEP-YAĞLAMA TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

902-4017
013-544



Model	Description
JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-YAĞLAMA-PLASTİK-EMNİYET YAY TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4018
013-545



DIMENSION: 2"

JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4050
013-580



DIMENSION: 2"

JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4051
013-581



DIMENSION: 2"

JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA-YAĞLAMA-PLASTİK TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4052
013-582



DIMENSION: 2"

JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KAMA-PLASTİK TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4053
013-583



DIMENSION: 2"

JOST	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-SABİTLEME KEP-YAĞLAMA TAMİR TAKIMI 2"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>
<p>Beşinci Teker / Fifth Wheel</p>	

902-4054
013-584



DIMENSION: 2"

Model	Description
JOST	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-YAĞLAMA-PLASTİK-EMNİYET YAY TAMİR TAKIMI 2"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>
Beşinci Teker / Fifth Wheel	

902-4055
013-585



Notes
1/1/1/1/4/1/1/2/2 Pcs

DIMENSION: 2"

JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5" (AYAKSIZ)</p> <p>(EN) Fifth Wheel 3,5" (Only Casting)</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK 38 C1</p> <p>JSK38C1</p> <p>JSK 38C1</p>
Beşinci Teker / Fifth Wheel		

903-1000
013-212



Notes
Kit

DIMENSION: 3,5"

JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5"-2" AYAKSIZ (2" DÜŞÜRÜLMÜŞ)</p> <p>(EN) Fifth Wheel 3,5"-2" (Only Casting)</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK 38 C1</p> <p>JSK38C1</p> <p>JSK 38C1</p>
Beşinci Teker / Fifth Wheel		

903-1001
013-212-1S1



Notes
Kit

DIMENSION: 3,5"-2"

JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5" AYAKLI H160</p> <p>(EN) Fifth Wheel 3,5" H160</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK 38 C1</p> <p>JSK38C1</p> <p>JSK 38C1</p> <p>JSK37C150ZJ</p> <p>JSK38C1S160ZS</p>
Beşinci Teker / Fifth Wheel		

903-1002
013-212-1S2



Notes
Kit

DIMENSION: 3,5"

JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5"-2" AYAKLI H160 (2" DÜŞÜRÜLMÜŞ)</p> <p>(EN) Fifth Wheel 3,5"-2" H160</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK 38 C1</p> <p>JSK38C1</p> <p>JSK 38C1</p>
Beşinci Teker / Fifth Wheel		

903-1003
013-212-1S3



Notes
Kit

DIMENSION: 3,5"-2"







JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5" AYAKLI H190</p> <p>(EN) Fifth Wheel 3,5" H190</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	<p>JSK 38 C1</p> <p>JSK38C1</p> <p>JSK38C1</p> <p>JSK37C185ZJ</p> <p>JSK38C1S190ZS</p>
Beşinci Teker / Fifth Wheel		

903-1004
013-212-1S4




Notes
Kit


DIMENSION: 3,5"

Model	Description		
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5"-2" AYAKLI H190 (2" DÜŞÜRÜLMÜŞ)</p> <p>(EN) Fifth Wheel 3,5"-2" H190</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	JSK 38 C1 JSK38C1 JSK 38C1	<p>903-1005 013-212-1S5</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5" AYAKLI H250</p> <p>(EN) Fifth Wheel 3,5" H250</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	JSK 38 C1 JSK38C1 JSK 38C1 JSK38C1S250ZS JSK37C250ZJ	<p>903-1006 013-212-1S6</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3,5"-2" AYAKLI H250 (2" DÜŞÜRÜLMÜŞ)</p> <p>(EN) Fifth Wheel 3,5"-2" H250</p> <p>(DE) Sattelkupplung</p> <p>(FR) 5e roue</p> <p>(ES) 5ª Rueda</p> <p>(PT) 5ª Roda</p> <p>(RU) Опорно-сцепное устройство</p>	JSK 38 C1 JSK38C1 JSK 38C1	<p>903-1007 013-212-1S7</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) 3,5" AYAĞI H160</p> <p>(EN) Pedestal, Fifth Wheel</p> <p>(DE) Sockel, Sattelkupplung</p> <p>(FR) Piédestal, 5e roue</p> <p>(ES) Placa, La Quinta Ruedae, 5ª Rueda</p> <p>(PT) Pedestal, Roda quinta</p> <p>(RU) Подрамник ОСУ, Опорно-сцепное устройство</p>	SK 2404-05 SK2404-05 SK240405 1118 A207-01	<p>903-2000 013-212-2S1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x1600mm	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) 3,5" AYAĞI H190</p> <p>(EN) Pedestal, Fifth Wheel</p> <p>(DE) Sockel, Sattelkupplung</p> <p>(FR) Piédestal, 5e roue</p> <p>(ES) Placa, La Quinta Ruedae, 5ª Rueda</p> <p>(PT) Pedestal, Roda quinta</p> <p>(RU) Подрамник ОСУ, Опорно-сцепное устройство</p>	SK 2404-01 SK2404-01 SK240401	<p>903-2001 013-212-2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x1900mm	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) 3,5" AYAĞI H250</p> <p>(EN) Pedestal, Fifth Wheel</p> <p>(DE) Sockel, Sattelkupplung</p> <p>(FR) Piédestal, 5e roue</p> <p>(ES) Placa, La Quinta Ruedae, 5ª Rueda</p> <p>(PT) Pedestal, Roda quinta</p> <p>(RU) Подрамник ОСУ, Опорно-сцепное устройство</p>	SK 2404-04 SK2404-04 SK240404 1118 A206-01	<p>903-2002 013-212-2S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x2500mm	


Model	Description		903-3000 013-271
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 3.5"</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	<p>SK 2405-14</p> <p>SK2405-14</p> <p>SK240514</p> <p>0834818</p> <p>118.027</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	







Model	Description		903-3001 013-273
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	<p>SK 2405-13</p> <p>SK2405-13</p> <p>SK240513</p> <p>2011701</p> <p>118.029</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	


Model	Description		903-3002 013-212-10
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 3.5" PİMİ</p> <p>(EN) Pin For Lock, Fifth Wheel</p> <p>(DE) Bolzen Für Verschlussshaken</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pasador De Seguridad</p> <p>(PT) Pino do eixo do gancho</p> <p>(RU) Фиксирующий штифт</p>	<p>SK 2405-18</p> <p>SK2405-18</p> <p>SK240518</p> <p>1659912</p> <p>101.318</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: Ø19,5x60	


Model	Description		903-3003 013-212-18
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KOLU-TOPUZ</p> <p>(EN) Locking Lever, Fifth Wheel</p> <p>(DE) Schloß Arm, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Palanca De Bloqueo, La Quinta Rueda</p> <p>(PT) Alavanca de bloqueio, Roda quinta</p> <p>(RU) Рычаг, Опорно-сцепное устройство</p>	<p>SK 2405-27</p> <p>SK2405-27</p> <p>SK240527</p> <p>0834822</p> <p>096.202</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3004 013-212-20
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) ve KİLİTLEME KOLU GERGİ YAYI</p> <p>(EN) Spring, Fifth Wheel</p> <p>(DE) Feder</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Muelle</p> <p>(PT) Mola</p> <p>(RU) Пружина</p>	<p>SK 2106-01</p> <p>SK2106-01</p> <p>SK210601</p> <p>0834820</p> <p>117.018</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: Ø20x87,5	


Model	Description		903-3005 013-212-19S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KOLU-TOPUZ SABİTLEME CIVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	<p>SK 2421-51</p> <p>SK2421-51s</p> <p>SK242151S</p> <p>0834823S</p> <p>102.567</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1,5x70	


Model	Description		
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KOLU-TOPUZ SABİTLEME CIVATA SOMUN</p> <p>(EN) Lock Nut</p> <p>(DE) Sicherungsmutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca</p> <p>(PT) Porca</p> <p>(RU) Самоконтрящаяся гайка</p>	104.107 SK 2421-51 SK2421-51 SK242151	<p>903-3006 013-212-19S1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CIVATASIZ 3.5"</p> <p>(EN) Wearing Ring, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	SK 2405-12 SK2405-12 SK240512 118.026	<p>903-3010 013-272-S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3.5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CIVATASIZ 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>(EN) Wearing Ring, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	SK 2405-11 SK2405-11 SK240511 118.028	<p>903-3011 013-274-S2</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3.5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CIVATASI</p> <p>(EN) Socket Head Bolt, Fifth Wheel</p> <p>(DE) Inbusbolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo, Bloqueo Jaw</p> <p>(PT) Parafuso, Cloqueio Jaw</p> <p>(RU) Болт</p>	SK 2421-08 SK2421-08 SK242108 S 0834817S 102.222	<p>903-3012 013-272-1S</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M12x1.75x22	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) EMNİYET YAYI</p> <p>(EN) Spring</p> <p>(DE) Feder</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Muelle</p> <p>(PT) Mola</p> <p>(RU) Пружина</p>	SK 2405-23 SK2405-23 SK240523 0834830 117.019	<p>903-3015 013-212-9</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI 3.5"</p> <p>(EN) Locking Bar, Fifth Wheel</p> <p>(DE) Achsschenkelbolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pestillo Cierre</p> <p>(PT) Gancho</p> <p>(RU) Шкворень</p>	SK 2405-01 SK2405-01 SK240501	<p>903-3016 013-263</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3017 013-212-4
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMA PİMİ</p> <p>(EN) Bolt For Lock</p> <p>(DE) Splint</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pasador Eje De Gancho</p> <p>(PT) Pino do eixo do gancho</p> <p>(RU) Фиксирующий штифт</p>	SK 2121-14 SK2121-14 SK212114	
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3018 013-212-5
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI SEKMANI</p> <p>(EN) Circlip for Lock Jaw, Fifth Wheel</p> <p>(DE) Sicherungsring</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pasador Eje De Gancho</p> <p>(PT) Pino do eixo do gancho</p> <p>(RU) Стопорное кольцо</p>	SK 2405-19 SK2405-19 SK240519	
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3019 013-212-6
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI GERĞİ YAYI</p> <p>(EN) Spring</p> <p>(DE) Feder</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Muelle</p> <p>(PT) Mola</p> <p>(RU) Пружина</p>		
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3020 013-212-8
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KARABİNALI ZİNCİR</p> <p>(EN) Spring Hook, Chain</p> <p>(DE) Karabinerhaken</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) Весна крюк, цепи и клин</p>	SK 3521-02 SK3521-02 SK352102	
Beşinci Teker / Fifth Wheel		DIMENSION: 690mm	


Model	Description		903-3021 013-212-11S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) 3,5" AYAR ÇİVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Sechskantschraube</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 2421-52 SK2421-52 SK242152S 102.568	
Beşinci Teker / Fifth Wheel		DIMENSION: M14x2x70	


Model	Description		903-3022 013-212-11S2
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) 3,5" AYAR ÇİVATA SOMUNU</p> <p>(EN) Hexagon Nut</p> <p>(DE) Sicherungsmutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca</p> <p>(PT) Porca</p> <p>(RU) Самоконтрящаяся гайка</p>	104.196	
Beşinci Teker / Fifth Wheel		DIMENSION: M14x2	


Model	Description		903-3023 013-212-12
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU</p> <p>(EN) Pull Handle</p> <p>(DE) Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla</p> <p>(PT) Perillo</p> <p>(RU) Рукоятка</p>	SK 2405-066 SK2405-066 SK2405066	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	


Model	Description		903-3024 013-212-15
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ARA KOLU</p> <p>(EN) Pull Handle</p> <p>(DE) Zuggriff</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla</p> <p>(PT) Perillo</p> <p>(RU) Рукоятка</p>	SK 2405-04 SK2405-04 SK240504	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	


Model	Description		903-3025 013-212-16
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ARA KOL SABİTLEME LAMASI</p> <p>(EN) Pull Handle Part</p> <p>(DE) Arm Bearing</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla, Parte</p> <p>(PT) Perillo, Parte</p> <p>(RU) Монтажные части</p>	SK 2405-15 SK2405-15 SK240515	
Notes 3,5"			
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	


Model	Description		903-3026 013-212-17S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ARA KOL SABİTLEME CİVATASI</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Sechskantschraube</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Perilla, Tornillo</p> <p>(PT) Perillo, Parafuso</p> <p>(RU) Болт</p>	SK 2421-53 SKS2421-53 SKS242153S 102.221	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M12x1.75x25	


Model	Description		903-3027 013-212-17S1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ARA KOL SABİTLEME CİVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Federscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela De Seguridad, Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 2421-53 SKS2421-53 SKS242153S 107.086	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: Ø12.5	


Model	Description		903-3030 013-283-1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK KAUÇUK TAKOZ 3.5" (ÜST)</p> <p>(EN) Mounting, Fifth Wheel</p> <p>(DE) Lager, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda</p> <p>(PT) Bomba sist. arrefecimento, Roda quinta</p> <p>(RU) Упруго-демпф. элемент, Сцепное y-vo</p>	SK 2006 SK2006 SK2006 0834134 095.057	
Notes Not Kit: 2 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3031 013-283-2
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK KAÇUK TAKOZ 3.5" (ALT)</p> <p>(EN) Mounting, Fifth Wheel</p> <p>(DE) Lager, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Montaje, La Quinta Rueda</p> <p>(PT) Bomba sist. arrefecimento, Roda quinta</p> <p>(RU) Упруго-демпф. элемент, Сцепное у-во</p>	SK 2007 SK2007 SK2007 095.058	
Beşinci Teker / Fifth Wheel		DIMENSION: x	



Model	Description		903-3032 013-293
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME KEPI</p> <p>(EN) Bracket</p> <p>(DE) Bridge Support</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bridge Support</p> <p>(PT) Bridge Support</p> <p>(RU) Особенная части</p>	SK 2005 SK2005 SK2005	
Beşinci Teker / Fifth Wheel		DIMENSION: x	


Model	Description		903-3033 013-212-3S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI M20x2.5x45</p> <p>(EN) Hexagon Head Screw</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo, Bridge Support</p> <p>(PT) Parafuso, Bridge Support</p> <p>(RU) Болт</p>	SK 2421-55 SK2421-55 SK242155S 0834836S	
Beşinci Teker / Fifth Wheel		DIMENSION: M20x2.5x45	


Model	Description		903-3034 013-212-3S1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Federscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca, Bridge Support</p> <p>(PT) Arruela, Bridge Support</p> <p>(RU) Шайба</p>		
Beşinci Teker / Fifth Wheel		DIMENSION: Ø20	


Model	Description		903-4000 013-271-1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 3.5" Cırtlı</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2405-14 Z SK2405- 14 Z SK240514Z 118.052	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	


Model	Description		903-4001 013-273-1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA (Hilal) 3.5"-2" DÖNÜŞTÜRÜCÜ Cırtlı</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2405-13 Z SK2405-13 Z SK240513Z	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	


Model	Description		
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI CİVATALI 3.5"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2421-56 SK2421-56 SK242156 0834815 095.949	<p>903-4002 013-272</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI CİVATALI 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2421-57 SK2421-57 SK242157 2011398 096.803	<p>903-4003 013-274</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI CİVATASI</p> <p>EN Socket Head Bolt, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2421-08 SK2421-08 SK242108 0834817 102.222	<p>903-4004 013-272-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M12x1.75x22	
JOST DAF	<p>TR PLEYT (Beşinci Teker) KAUCUK TAKOZ TAMİR TAKIMI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>		<p>903-4005 013-283</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>TR PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2421-55 SK2421-55 SK242155 0834836 095.537	<p>903-4006 013-212-3</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M20x45	
JOST DAF	<p>TR PLEYT (Beşinci Teker) KAUCUK TAKOZ TAMİR TAKIMI 3.5" CİVATALI</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	SK 2421-78 SK2421-78 SK242178 095.536	<p>903-4007 013-666</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	


Model	Description		903-4008 013-212-19
JOST DAF	<p>TR PLEYT (Beşinci Teker) TOPUZ SABİTLEME CİVATASI PULLU SOMUNLU TAKIM</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-51</p> <p>SK2421-51</p> <p>SK242151</p> <p>0834823</p> <p>096.530</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5x70	

JOST DAF	<p>TR PLEYT (Beşinci Teker) ARA KOL SABİTLEME CİVATASI PULLU TAKIM</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-53</p> <p>SK2421-53</p> <p>SK242153</p> <p>096.532</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: M12x25	

JOST DAF	<p>TR PLEYT (Beşinci Teker) 3,5" AYAR CİVATASI TAKIM</p> <p>EN Hexagon Head Screw</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-52</p> <p>SK2421-52</p> <p>SK242152</p> <p>096.531</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: M14x2x70	

JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 3.5"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-98</p> <p>SK2421-98</p> <p>SK242198</p> <p>0834837</p> <p>095.658</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	

JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT CİRTLİ TAMİR TAKIMI 3.5"</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-98</p> <p>Z SK2421-98 Z</p> <p>SK242198Z</p> <p>1659941</p> <p>095.657</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	

JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT TAMİR TAKIMI 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>	<p>SK 2421-99</p> <p>SK2421-99</p> <p>SK242199</p> <p>0834838</p> <p>095.554</p>	
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	

Model	Description		
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT CİRTLİ TAMİR TAKIMI 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-99 Z SK2421-99 Z SK242199Z 0882678 095.659	<p>903-4033 013-660-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT -KİLİT KANCA-CİRT TAMİR TAKIMI 3.5"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-76 SK2421-76 SK242176 1365406 095.549	<p>903-4034 013-626</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT -KİLİT KANCA-CİRT-YAĞLAMA TAMİR TAKIMI 3.5"</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-76 Z SK2421-76 Z SK242176Z	<p>903-4035 013-627</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT -KİLİT KANCA-CİRT TAMİR TAKIMI 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-77 SK2421-77 SK242177 0882676 095.550	<p>903-4036 013-628</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT -KİLİT KANCA-CİRT-YAĞLAMA TAMİR TAKIMI 3.5"-2" DÖNÜŞTÜRÜCÜ</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2421-77 Z SK2421-77 Z SK242177Z 0882677 095.660	<p>903-4037 013-629</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"-2"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker) ÇEKME KOLU CİVATALI ZİNCİRLİ TAMİR TAKIMI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 3121-063 SK3121-063 SK3121063 1323312 095.551	<p>903-4040 013-630</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	

Model **Description**

JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI TAMİR TAKIMI 3.5"
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes
Kit: 1/1/1/1/3 Pcs

Beşinci Teker / Fifth Wheel

DIMENSION: 3,5"

903-4050
013-621



JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI- KAUCUK TAKOZ TAMİR TAKIMI 3.5"
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes
Kit: 1/1/1/1/3/2/2 Pcs

Beşinci Teker / Fifth Wheel

DIMENSION: 3,5"

903-4051
013-622



JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-YAĞLAMALI TAMİR TAKIMI 3.5"
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes
Kit: 1/1/1/1/1/3/2/2 Pcs

Beşinci Teker / Fifth Wheel

DIMENSION: 3,5"

903-4052
013-623



JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-AYAK KEPI-YAĞLAMALI TAMİR TAKIMI 3.5"
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes
Kit: 1/1/1/1/1/3/2/2/2 Pcs

Beşinci Teker / Fifth Wheel

DIMENSION: 3,5"

903-4053
013-624



JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-CİVATALI-YAĞLAMALI TAMİR TAKIMI 3.5"
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство

Notes
Kit: 1/1/1/1/1/3/2/2/8/8 Pcs

Beşinci Teker / Fifth Wheel

DIMENSION: 3,5"

903-4054
013-625



JOST | DAF

- TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI TAMİR TAKIMI 3.5"-2" DÖNÜŞTÜRÜCÜ
- EN Repair Kit, Fifth Wheel
- DE Reparatursatz, Sattelkupplung
- FR Kit de Réparation, 5e roue
- ES Kit Reparación Anillo 5º
- PT Jogo de reparo, Roda quinta
- RU Ремонтный комплект, Сцепное устройство






Notes
Kit: 1/1/1/1/3 Pcs



Beşinci Teker / Fifth Wheel


DIMENSION: 3,5"-2"


903-4080
013-661



Model	Description		
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI- KAUCUK TAKOZ TAMİR TAKIMI 3,5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>		<p>903-4081 013-662</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"-2"
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-AYAĞ KEPI-YAĞLAMALI TAMİR TAKIMI 3,5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>		<p>903-4082 013-663</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"-2"
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-AYAK KEPI-YAĞLAMALI TAMİR TAKIMI 3,5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>		<p>903-4083 013-664</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"-2"
JOST DAF	<p>TR PLEYT (Beşinci Teker) AŞINMA AYI-KİLİT-KİLİTLEME KAMASI-EMNİYET YAYI-KAUCUK TAKOZ-CIVATALI-YAĞLAMALI TAMİR TAKIMI 3,5"-2" DÖNÜŞTÜRÜCÜ</p> <p>EN Repair Kit, Fifth Wheel</p> <p>DE Reparatursatz, Sattelkupplung</p> <p>FR Kit de Réparation, 5e roue</p> <p>ES Kit Reparación Anillo 5º</p> <p>PT Jogo de reparo, Roda quinta</p> <p>RU Ремонтный комплект, Сцепное устройство</p>		<p>903-4084 013-665</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"-2"
JOST DAF	<p>TR PLEYT (Beşinci Teker)3,5" MAFSALLI</p> <p>EN Fifth Wheel 3,5" H190 ARTICULATION TYPE</p> <p>DE Sattelkupplung</p> <p>FR Partie, 5e roue</p> <p>ES 5ª Rueda</p> <p>PT 5ª Roda</p> <p>RU Опорно-сцепное устройство</p>	<p>JSK 38 G1 JSK38G1 JSK38G1</p>	<p>904-1000 013-211</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"
JOST DAF	<p>TR PLEYT (Beşinci Teker) 3,5" MAFSALLI AYAĞI H290</p> <p>EN Pedestal, Fifth Wheel</p> <p>DE Sockel, Sattelkupplung</p> <p>FR Partie, 5e roue</p> <p>ES Placa, La Quinta Ruedae, 5ª Rueda</p> <p>PT Pedestal, Roda quinta</p> <p>RU Подрамник ОСУ, Опорно-сцепное устройство</p>	<p>SK 2521-52 SK2521-52 SK252152</p>	<p>904-2000 013-211-2</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 3,5"


Model	Description		
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL KÜTÜĞÜ</p> <p>(EN) Rocker Arm</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-цепное устройство</p>	SK 2521-51 SK2521-51 SK252151	<p>904-2001 013-211-1</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL BURCU</p> <p>(EN) Plastic Bushing</p> <p>(DE) Buchse</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Buje De Plastico</p> <p>(PT) Bucsa De Plástico</p> <p>(RU) пластмас Втулка</p>	SK 2504-16 SK2504-16 SK250416	<p>904-3000 013-211-3</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEME PERNOSU</p> <p>(EN) Pivot Pin</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-цепное устройство</p>	SK 2504-17 SK2504-17 SK250417	<p>904-3001 013-211-4</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEYİCİ DÖKÜM</p> <p>(EN) Mounting Casting</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-цепное устройство</p>	SK 2506-22 SK2506-22 SK250622	<p>904-3002 013-211-5</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL DAYANAĞI</p> <p>(EN) Spare Parts</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-цепное устройство</p>	SK 2506-35 SK2506-35 SK250635	<p>904-3003 013-211-6</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5"	
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEME CIVATASI</p> <p>(EN) Bolt</p> <p>(DE) Kunststoffbüchse</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) БОЛТ</p>	SK 2521-18 SK2521-18 SK252118	<p>904-3004 013-211-7</p> 
Beşinci Teker / Fifth Wheel		DIMENSION: M14x35	


Model	Description		904-3005 013-211-8
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEME CİVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 2504-21 SK2504-21 SK250421	
Beşinci Teker / Fifth Wheel		DIMENSION: Ø14	

JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEME CİVATA PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 2504-20 SK2504-20 SK250420	904-3006 013-211-17	
Beşinci Teker / Fifth Wheel		DIMENSION: Ø20		


JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL DENGİ PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 2504-14 SK2504-14 SK250414	904-3007 013-211-9	
Beşinci Teker / Fifth Wheel		DIMENSION: 10mm		


JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL DENGİ PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	SK 1192/1 SK1192/1 SK11921	904-3008 013-211-14	
Beşinci Teker / Fifth Wheel		DIMENSION: 8mm		


JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL O'RING</p> <p>(EN) O-Ring</p> <p>(DE) O-Ring</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Junta Tórica</p> <p>(PT) Anel de vedação-O</p> <p>(RU) Уплотнительное кольцо круглого</p>	SK 2521-07 SK2521-07 SK252107	904-3009 013-211-11	
Beşinci Teker / Fifth Wheel		DIMENSION: Ø95		


JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI BURÇ SABİTLEME CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) БОЛТ</p>	SK 1533 SK1533 SK1533	904-3010 013-211-12	
Beşinci Teker / Fifth Wheel		DIMENSION: M12x20		


Model	Description		904-3011 013-211-15
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI AYAK SEKMANI</p> <p>(EN) Circlip for Lock Jaw</p> <p>(DE) Sicherungsring</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Arruela</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 1435 SK1435 SK1435	
Notes Kit: 2 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: x	







Model	Description		904-3012 013-211-13
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI YAĞLAMA GRESÖRLÜĞÜ</p> <p>(EN) Cylindrical Pin</p> <p>(DE) Schmiernippel</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Boquilla De Engrase</p> <p>(PT) Graxeira</p> <p>(RU) Смазка ниппель</p>	SK 2521-04 SK2521-04 SK252104 06380700102 5005097023 06380702102	
Notes Kit: 6 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M18x1	







Model	Description		904-3013 013-211-19S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI AYAK SABİTLEME CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 2410-019 SKS2410-019 SKS2410019S	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M16x1.5x45	


Model	Description		904-3014 013-211-19S1
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI AYAK SABİTLEME CİVATA SOMUNU</p> <p>(EN) Bolt</p> <p>(DE) Sicherungsmutter</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tuerca</p> <p>(PT) Porca</p> <p>(RU) Гайка</p>	SK 2410-019 SK2410-019 SK2410019S	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M16x1.5	


Model	Description		904-3015 013-211-19
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSALLI AYAK SABİTLEME CİVATA TAKIMI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	SK 2410-019 SK2410-019 SK2410019	
Notes Kit: 4/4 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M16x1.5x45 / M16x1.5	


Model	Description		904-3016 013-211-20S
JOST DAF	<p>(TR) PLEYT (Beşinci Teker)3.5" MAFSAL SABİTLEME CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	SK 2521-50 SK2521-50 SK252150	
Notes Not Kit: 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5x25	


Model	Description		
JOST DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker)3,5" MAFSAL SABİTLEME CİVATASI EN Bolt DE Bolzen FR Partie, 5e roue ES Tornillo PT Parafuso RU Болт 	SK 2521-50 SK2521-50 SK252150	904-3017 013-211-20S1 
Beşinci Teker / Fifth Wheel		DIMENSION: Ø10	
JOST DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker)3,5" MAFSAL SABİTLEME CİVATASI EN Bolt DE Bolzen FR Partie, 5e roue ES Tornillo PT Parafuso RU Ремонтный комплект, Сцепное устройство 	SK 2521-50 SK2521-50 SK252150	904-3018 013-211-20 
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5x25/Ø10	
GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H150 GF TİPİ EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	NA	905-2000 013-237-1 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x1500mm	
GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H185 GF TİPİ EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	NA	905-2001 013-237-2 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x1850mm	
GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAĞI H220 GF TİPİ EN Pedestal, Fifth Wheel DE Sockel, Sattelkupplung FR Piédestal, 5e roue ES Placa, La Quinta Ruedae, 5ª Rueda PT Pedestal, Roda quinta RU Подрамник ОСУ, Опорно-сцепное устройство 	NA	905-2002 013-237-3 
Beşinci Teker / Fifth Wheel		DIMENSION: 3,5x2200mm	
GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) YÜKSELTMESİ 30mm GF TİPİ EN Raising Wedge, Fifth Wheel DE Keil, Sattelkupplung FR Partie, 5e roue ES Parte, 5ª Rueda PT Parte, 5ª roda RU часть, Опорно-сцепное устройство 	NA	905-2010 013-251 
Beşinci Teker / Fifth Wheel		DIMENSION: H30	


Model	Description		
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTMESİ 40mm GF TİPİ</p> <p>(EN) Raising Wedge, Fifth Wheel</p> <p>(DE) Keil, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	NA	<p>905-2011 013-246</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: H40
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTMESİ 50mm GF TİPİ</p> <p>(EN) Raising Wedge, Fifth Wheel</p> <p>(DE) Keil, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Parte, 5ª Rueda</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	NA	<p>905-2012 013-245</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: H50
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) 2" KİLİT KANCA</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Опорно-сцепное устрой</p>	662 129 134 662129134 662129134 1397014	<p>905-3000 013-279</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) 2" KİLİT KANCA</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Опорно-сцепное устрой</p>		<p>905-3001 013-952</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) 2" KİLİT KANCA PİMİ</p> <p>(EN) Bolt For Lock</p> <p>(DE) Bolzen Für Verschlussshaken</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Pasador De Seguridad</p> <p>(PT) Pino do eixo do gancho</p> <p>(RU) Фиксирующий штифт</p>	662 129 375 662129375 662129375 1397016	<p>905-3002 013-215-3</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA SEKMANI</p> <p>(EN) Circlip for Lock Jaw, Fifth Wheel</p> <p>(DE) Sicherungsring</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Circlip</p> <p>(PT) Arruela</p> <p>(RU) Кольцо частей</p>	659 100 027 659100027 1397022	<p>905-3003 013-215-4</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"

Model	Description		905-3004 013-215-5
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA PULU</p> <p>(EN) Washer</p> <p>(DE) Scheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Arandela</p> <p>(PT) Arruela</p> <p>(RU) Шайба</p>	659 100 026 659100026 659100026	
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA BURCU</p> <p>(EN) Bushing</p> <p>(DE) Buchse</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) Вставка Ресорная</p>		905-3005 013-215-6
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİT KANCA YAYI</p> <p>(EN) Spring</p> <p>(DE) Feder, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Muelle, La Quinta Rueda</p> <p>(PT) Mola</p> <p>(RU) Пружина, Опорно-цепное устройство</p>	662 126 411 662126411 662126411	905-3006 013-215-1
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMASI 2"</p> <p>(EN) Locking Bolt, Fifth Wheel</p> <p>(DE) Schloß Keil, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) Стопорный болт, Сцепное устройство</p>	662 129 381 662129381 662129381	905-3007 013-265
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KİLİTLEME KAMA CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen, Schloß Keil</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo</p> <p>(PT) Parafuso</p> <p>(RU) Болт</p>	662 129 600 662129600 662129600	905-3008 013-215-2
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: M20x40	

GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI 2" (CİVATASIZ)</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	662 129 377 662129377 662129377 1397017	905-3009 013-280-10
Notes Not Kit 1 Pcs			
Beşinci Teker / Fifth Wheel		DIMENSION: 2"	

Model	Description	
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI 2" (CİVATASIZ)</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	<p>662 126 202</p> <p>662126202</p> <p>662126202</p> <p>836758</p>
Notes Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

905-3010
013-951-10



GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI 2" (CİVATASIZ)</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Schloß Kinn, Sattelkupplung</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Cloqueio Jaw, Roda quinta</p> <p>(RU) Блокировка зажима, Сцепное устройство</p>	<p>662 126 229</p> <p>662126229</p> <p>662126229</p>
Notes Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: 2"

905-3011
013-950-10



GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA AYI CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen, Schloß Kinn</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo, Bloqueo Jaw</p> <p>(PT) Cloqueio Jaw, Parafuso</p> <p>(RU) БОЛТ</p>	<p>659 112 372</p> <p>659112372</p> <p>662 126 155</p> <p>662126155</p> <p>0836759</p> <p>1397021</p>
Notes Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M10x25

905-3012
013-280-1



GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ (CİVATASIZ)</p> <p>(EN) Lock Jaw, Fifth Wheel</p> <p>(DE) Gleitscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Bloqueo Jaw, La Quinta Rueda</p> <p>(PT) Segmentos de nylon</p> <p>(RU) Пластина</p>	<p>662 131 103</p> <p>662131103</p> <p>662131103</p> <p>1397096</p>
Notes Not Kit 2 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: x

905-3013
013-802-1



GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ CİVATASI</p> <p>(EN) Bolt</p> <p>(DE) Bolzen, Gleitscheibe</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Tornillo, Bloqueo Jaw</p> <p>(PT) Parafuso, Segmentos de nylon</p> <p>(RU) БОЛТ</p>	<p>662 130 114S</p> <p>662130114S</p> <p>662130114S</p> <p>1397097S</p>
Notes Not Kit 1 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: M10x1.5/20


905-3014
013-802-3S





GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) KAÜÇUK TAKOZ</p> <p>(EN) Rubber Bearing</p> <p>(DE) Gummibüchse</p> <p>(FR) Partie, 5e roue</p> <p>(ES) Buje Para Quinta Rueda</p> <p>(PT) Bucha de borracha</p> <p>(RU) резиновый Резиновая</p>	<p>662 114 110</p> <p>662114110</p> <p>662114110</p> <p>1397018</p>
Notes Not Kit 2 Pcs		
Beşinci Teker / Fifth Wheel		DIMENSION: x


905-3015
013-286-1





Model	Description		905-3016 013-286-2
GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) PLASTİK TAKOZ EN Plastic Bearing DE Kunststofflager FR Partie, 5e roue ES Kit De Reparación, Barra Del Eje PT Jogo de reparo, Haste do eixo RU пластмас Подшипник 	662 130 101 662130101 662130101 1397019	
Beşinci Teker / Fifth Wheel			DIMENSION: x


GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI ANAHTAR BAŞLI EN Bolt DE Bolzen, Sockel FR Partie, 5e roue ES Tornillo PT Parafuso RU БОЛТ 	662 129 606S 662129606S 1397023S	905-3017 013-296-1	
Beşinci Teker / Fifth Wheel				DIMENSION: M20x80


GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI ALYAN BAŞLI EN Bolt DE Bolzen, Sockel FR Partie, 5e roue ES Tornillo PT Parafuso RU БОЛТ 	659 112 365S 659112365S 1397076S	905-3018 013-296-H1	
Beşinci Teker / Fifth Wheel				DIMENSION: M20x70


GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AŞINMA AYI 2" CİVATALI EN Repair Kit, Fifth Wheel DE Reparatursatz, Sattelkupplung FR Kit de Réparation, 5e roue ES Kit Reparación Anillo 5º PT Jogo de reparo, Roda quinta RU Ремонтный комплект, Сцепное устройство 	662 101 566 662101566 662101566 1831321 096.501	905-4000 013-280	
Beşinci Teker / Fifth Wheel				DIMENSION: 2"


GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AŞINMA AYI 2" CİVATALI EN Repair Kit, Fifth Wheel DE Reparatursatz, Sattelkupplung FR Kit de Réparation, 5e roue ES Kit Reparación Anillo 5º PT Jogo de reparo, Roda quinta RU Ремонтный комплект, Сцепное устройство 	662 101 338 662101338 662101338	905-4001 013-951	
Beşinci Teker / Fifth Wheel				DIMENSION: 2"


GEORG FISCHER (GF) DAF	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) AŞINMA AYI 2" CİVATALI EN Repair Kit, Fifth Wheel DE Reparatursatz, Sattelkupplung FR Kit de Réparation, 5e roue ES Kit Reparación Anillo 5º PT Jogo de reparo, Roda quinta RU Ремонтный комплект, Сцепное устройство 	662 101 562 662101562 662101562	905-4002 013-950	
Beşinci Teker / Fifth Wheel				DIMENSION: 2"


Model	Description		905-4003 013-802
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ CİVATALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 469 662101469 662101469 1618988	
Beşinci Teker / Fifth Wheel			DIMENSION: 2"

Model	Description		905-4004 013-802-3
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AŞINMA PLASTİĞİ CİVATASI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 130 114 662130114 662130114 1397097	
Beşinci Teker / Fifth Wheel			DIMENSION: 2"

Model	Description		905-4005 013-286
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>		
Beşinci Teker / Fifth Wheel			DIMENSION: 2"







Model	Description		905-4006 013-296
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI M20x80</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 129 606 662129606 662129606 1397023	
Beşinci Teker / Fifth Wheel			DIMENSION: M20x80

Model	Description		905-4007 013-296-H
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) AYAK SABİTLEME CİVATASI M20x70</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	659 112 365 659112365 659112365 1397076	
Beşinci Teker / Fifth Wheel			DIMENSION: M20x70

Model	Description		905-4008 013-703
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI 2" ANAHTAR BAŞLI CİVATALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 473 662101473 662101473 1397025	
Beşinci Teker / Fifth Wheel			DIMENSION: 2"

Model	Description		
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) PLASTİK TAMİR TAKIMI 2" HAVŞA BAŞLI CİVATALI</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 518 662101518 662101518 1397078	<p>905-4009 013-703-1</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) TAMİR TAKIMI 2" KİLİT-AŞINMA AYI-PİM-SEKMAN</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 492 662101492 662101492 1397024	<p>905-4010 013-700</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) TAMİR TAKIMI 2" KİLİT-AŞINMA AYI-PLASTİK-KAUCUK-PİM-CİVATA</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 493 662101493 662101493 9506116	<p>905-4011 013-701</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) TAMİR TAKIMI 2" KİLİT-AŞINMA AYI-PLASTİK-KAUCUK-PİM-HB.CİVATA</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>	662 101 516 662101516 662101516	<p>905-4012 013-701-1</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
GEORG FISCHER (GF) DAF	<p>(TR) PLEYT (Beşinci Teker) TAMİR TAKIMI 2" KİLİT-AŞINMA AYI-PİM-KİLİT-LEME KAMA-KAMA CİVATASI-SEKMAN</p> <p>(EN) Repair Kit, Fifth Wheel</p> <p>(DE) Reparatursatz, Sattelkupplung</p> <p>(FR) Kit de Réparation, 5e roue</p> <p>(ES) Kit Reparación Anillo 5º</p> <p>(PT) Jogo de reparo, Roda quinta</p> <p>(RU) Ремонтный комплект, Сцепное устройство</p>		<p>905-4013 013-705</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h30</p> <p>(EN) Corrugated Mounting Plate h30, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 75011-00 SK75011-00 SK7501100	<p>915-1000 013-221-30</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h30

Model	Description		
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h50</p> <p>(EN) Corrugated Mounting Plate h50, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 75011-00 SK75011-00 SK7501100	<p>915-1001 013-221-50</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h50
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h70</p> <p>(EN) Corrugated Mounting Plate h70, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 75011-00 SK75011-00 SK7501100	<p>915-1002 013-221-70</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h70
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h80</p> <p>(EN) Corrugated Mounting Plate h80, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>		<p>915-1003 013-221-80</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h80
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h90</p> <p>(EN) Corrugated Mounting Plate h90, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	MP 2102 MP2102 MP-2102 SK 75011-00 SK75011-00 SK7501100	<p>915-1004 013-221-90</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h90
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI h150</p> <p>(EN) Corrugated Mounting Plate h150, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 75011-00 SK75011-00 SK7501100	<p>915-1005 013-221-150</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: h150
Fifth Wheel Base Plate	<p>(TR) PLEYT (Beşinci Teker) YÜKSELTME SEHPASI DÜZ</p> <p>(EN) Corrugated Mounting Plate, Fifth Wheel</p> <p>(DE) Gewellte Montageplatte</p> <p>(FR) Partie, 5e roue</p> <p>(ES) 5ª Rueda, Parte</p> <p>(PT) Parte, 5ª roda</p> <p>(RU) часть, Опорно-сцепное устройство</p>	SK 75011-00 SK75011-00 SK7501100	<p>915-1006 013-222</p> 
Beşinci Teker / Fifth Wheel			DIMENSION: DÜZ

Model	Description		
Fifth Wheel Base Plate	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) YÜKSELTME SEHPASI 10mm h40 EN Corrugated Mounting Plate 10mm h40, Fifth Wheel DE Gewellte Montageplatte FR Partie, 5e roue ES 5ª Rueda, Parte PT Parte, 5ª roda RU часть, Опорно-сцепное устройство 	SK 75011-00 SK75011-00 SK7501100	915-1007 013-221-40S
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: h40
Fifth Wheel King Pin	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) KİNG PİMİ 2" EN King Pin 2" DE Königspin FR Partie, 5e roue ES Reparación, La Quinta Rueda PT King Pin, Roda quinta RU Шкворень, Опорно-сцепное устройство 	SZ 1012 SZ1012	915-2000 012-523
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
Fifth Wheel King Pin	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) KİNG PİMİ KAFASI 2" EN King Pin 2" (Head) DE Königspin FR Partie, 5e roue ES Reparación, La Quinta Rueda PT King Pin, Roda quinta RU Шкворень, Опорно-сцепное устройство 	SZ 1012-01 SZ1012-01	915-2001 012-501
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: 2"
Fifth Wheel King Pin	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) KİNG PİMİ 3.5" EN King Pin 3.5" DE Königspin FR Partie, 5e roue ES Reparación, La Quinta Rueda PT King Pin, Roda quinta RU Шкворень, Опорно-сцепное устройство 	SZ 1412 SZ1412	915-2002 012-502
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: 3.5"
Fifth Wheel King Pin	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) KİNG PİMİ KAFASI 3.5" EN King Pin 3.5" (Head) DE Königspin FR Partie, 5e roue ES Reparación, La Quinta Rueda PT King Pin, Roda quinta RU Шкворень, Опорно-сцепное устройство 	SZ 1412-01 SZ1412-01	915-2003 012-503
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: 3.5"
Fifth Wheel King Pin	<ul style="list-style-type: none"> TR PLEYT (Beşinci Teker) KİNG PİMİ TASI EN King Pin Spare Part DE Königspin FR Partie, 5e roue ES Reparación, La Quinta Rueda PT King Pin, Roda quinta RU Шкворень, Опорно-сцепное устройство 	SZ 1012-04 SZ1012-04	915-2004 012-504
Notes x			
Beşinci Teker / Fifth Wheel			DIMENSION: x

Model

Fifth Wheel King Pin

Description

- TR PLEYT (Beşinci Teker) KİNG PİMİ APARATI 3.5"-2"
- EN King Pin Apparatus 3.5"-2"
- DE Königspin
- FR Partie, 5e roue
- ES Reparación, La Quinta Rueda
- PT King Pin, Roda quinta
- RU Шкворень, Опорно-сцепное устройство

Notes

x

915-2005
012-505

Beşinci Teker / Fifth Wheel

DIMENSION: 3.5"-2"

CONTAINER SPARE PARTS



Model	Description
-------	-------------

- | | |
|-----------|----------------------------|
| Container | (TR) KONTEYNER KÖŞESİ SAĞ |
| | (EN) Container Lock, Right |
| | (DE) Container Lock, Right |
| | (FR) Container Lock, Right |
| | (ES) Container Lock, Right |
| | (PT) Container Lock, Right |
| | (RU) Container Lock, Right |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3000
013-349-R



- | | |
|-----------|---------------------------|
| Container | (TR) KONTEYNER KÖŞESİ SOL |
| | (EN) Container Lock, Left |
| | (DE) Container Lock, Left |
| | (FR) Container Lock, Left |
| | (ES) Container Lock, Left |
| | (PT) Container Lock, Left |
| | (RU) Container Lock, Left |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3001
013-349-L



- | | |
|-----------|---|
| Container | (TR) KONTEYNER KİLİDİ ÇİFTLİ MODEL (50MM) |
| | (EN) Container Lock Double Type (50mm) |
| | (DE) Container Lock Double Type (50mm) |
| | (FR) Container Lock Double Type (50mm) |
| | (ES) Container Lock Double Type (50mm) |
| | (PT) Container Lock Double Type (50mm) |
| | (RU) Container Lock Double Type (50mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3002
013-325



- | | |
|-----------|--|
| Container | (TR) KONTEYNER KİLİDİ KASASI ÇİFTLİ MODEL (50MM) |
| | (EN) Container Lock Spare Part |
| | (DE) Container Lock Spare Part |
| | (FR) Container Lock Spare Part |
| | (ES) Container Lock Spare Part |
| | (PT) Container Lock Spare Part |
| | (RU) Container Lock Spare Part |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3003
013-325-1



- | | |
|-----------|------------------------------|
| Container | (TR) KONTEYNER KİLİDİ (50MM) |
| | (EN) Container Lock (50mm) |
| | (DE) Container Lock (50mm) |
| | (FR) Container Lock (50mm) |
| | (ES) Container Lock (50mm) |
| | (PT) Container Lock (50mm) |
| | (RU) Container Lock (50mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3004
013-326



- | | |
|-----------|--|
| Container | (TR) KONTEYNER KİLİT KASASI TEKLİ (50MM) |
| | (EN) Container Lock Spare Part |
| | (DE) Container Lock Spare Part |
| | (FR) Container Lock Spare Part |
| | (ES) Container Lock Spare Part |
| | (PT) Container Lock Spare Part |
| | (RU) Container Lock Spare Part |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3005
013-326-5



Model	Description
-------	-------------

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT MİLİ (50MM)</p> <p>(EN) Container Lock Pin (50mm)</p> <p>(DE) Container Lock Pin (50mm)</p> <p>(FR) Container Lock Pin (50mm)</p> <p>(ES) Container Lock Pin (50mm)</p> <p>(PT) Container Lock Pin (50mm)</p> <p>(RU) Container Lock Pin (50mm)</p> |
|-----------|---|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3006
013-326-1



- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT SOMUNU (50MM)</p> <p>(EN) Container Lock Nut (50mm)</p> <p>(DE) Container Lock Nut (50mm)</p> <p>(FR) Container Lock Nut (50mm)</p> <p>(ES) Container Lock Nut (50mm)</p> <p>(PT) Container Lock Nut (50mm)</p> <p>(RU) Container Lock Nut (50mm)</p> |
|-----------|---|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3007
013-326-2



- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİT MERKEZLEYİCİSİ</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|--|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3008
013-326-3



- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİT SEKMANI (50MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|--|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3009
013-326-4



- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİDİ KOLLU MERKEZLEYİCİ 50 MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|---|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3010
013-326-6



- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİT MİL ve SOMUNU (50MM)</p> <p>(EN) Container Lock Repair Kit (50mm)</p> <p>(DE) Container Lock Repair Kit (50mm)</p> <p>(FR) Container Lock Repair Kit (50mm)</p> <p>(ES) Container Lock Repair Kit (50mm)</p> <p>(PT) Container Lock Repair Kit (50mm)</p> <p>(RU) Container Lock Repair Kit (50mm)</p> |
|-----------|--|

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3011
013-333-1



Model	Description
-------	-------------

- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİDİ TAMİR TAKIMI (50MM)</p> <p>(EN) Container Lock Repair Kit (50mm)</p> <p>(DE) Container Lock Repair Kit (50mm)</p> <p>(FR) Container Lock Repair Kit (50mm)</p> <p>(ES) Container Lock Repair Kit (50mm)</p> <p>(PT) Container Lock Repair Kit (50mm)</p> <p>(RU) Container Lock Repair Kit (50mm)</p> |
|-----------|--|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3012
013-333



- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİDİ ÇİFTLİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Double Medium Type (38mm)</p> <p>(DE) Container Lock Double Medium Type (38mm)</p> <p>(FR) Container Lock Double Medium Type (38mm)</p> <p>(ES) Container Lock Double Medium Type (38mm)</p> <p>(PT) Container Lock Double Medium Type (38mm)</p> <p>(RU) Container Lock Double Medium Type (38mm)</p> |
|-----------|---|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3020
013-327



- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT KASASI ÇİFTLİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|---|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3021
013-327-1



- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİDİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Medium Type (38mm)</p> <p>(DE) Container Lock Medium Type (38mm)</p> <p>(FR) Container Lock Medium Type (38mm)</p> <p>(ES) Container Lock Medium Type (38mm)</p> <p>(PT) Container Lock Medium Type (38mm)</p> <p>(RU) Container Lock Medium Type (38mm)</p> |
|-----------|--|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3022
013-328



- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİT KASASI TEKLİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|--|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3023
013-328-5



- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT MİLİ (38MM)</p> <p>(EN) Container Lock Pin (38mm)</p> <p>(DE) Container Lock Pin (38mm)</p> <p>(FR) Container Lock Pin (38mm)</p> <p>(ES) Container Lock Pin (38mm)</p> <p>(PT) Container Lock Pin (38mm)</p> <p>(RU) Container Lock Pin (38mm)</p> |
|-----------|---|

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3024
013-328-1



Model	Description
-------	-------------

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT SOMUNU (38MM)</p> <p>(EN) Container Lock Nut (38mm)</p> <p>(DE) Container Lock Nut (38mm)</p> <p>(FR) Container Lock Nut (38mm)</p> <p>(ES) Container Lock Nut (38mm)</p> <p>(PT) Container Lock Nut (38mm)</p> <p>(RU) Container Lock Nut (38mm)</p> |
|-----------|---|

Notes
X

915-3025
013-328-2



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT SEKMANI ORTA MODEL (38MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|---|

Notes
X

915-3026
013-328-4



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT ORTA MERKEZLEYİCİSİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|---|

Notes
X

915-3027
013-328-3



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

- | | |
|-----------|--|
| Container | <p>(TR) KONTEYNER KİLİT KOLLU MERKEZLEYİCİSİ ORTA MODEL (38MM)</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p> |
|-----------|--|

Notes
X

915-3028
013-328-6



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİT MİL ve SOMUNU ORTA MODEL (38MM)</p> <p>(EN) Container Lock Repair Kit Medium Type (38mm)</p> <p>(DE) Container Lock Repair Kit Medium Type (38mm)</p> <p>(FR) Container Lock Repair Kit Medium Type (38mm)</p> <p>(ES) Container Lock Repair Kit Medium Type (38mm)</p> <p>(PT) Container Lock Repair Kit Medium Type (38mm)</p> <p>(RU) Container Lock Repair Kit Medium Type (38mm)</p> |
|-----------|---|

Notes
X

915-3029
013-334-1



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

- | | |
|-----------|---|
| Container | <p>(TR) KONTEYNER KİLİDİ TAMİR TAKIMI ORTA MODEL (38MM)</p> <p>(EN) Container Lock Repair Kit Medium Type (38mm)</p> <p>(DE) Container Lock Repair Kit Medium Type (38mm)</p> <p>(FR) Container Lock Repair Kit Medium Type (38mm)</p> <p>(ES) Container Lock Repair Kit Medium Type (38mm)</p> <p>(PT) Container Lock Repair Kit Medium Type (38mm)</p> <p>(RU) Container Lock Repair Kit Medium Type (38mm)</p> |
|-----------|---|

Notes
X

915-3030
013-334



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

Model	Description
-------	-------------

- | | |
|-----------|---|
| Container | (TR) KONTEYNER KİLİDİ ÇİFTLİ MODEL (38MM) |
| | (EN) Container Lock Double Type (38mm) |
| | (DE) Container Lock Double Type (38mm) |
| | (FR) Container Lock Double Type (38mm) |
| | (ES) Container Lock Double Type (38mm) |
| | (PT) Container Lock Double Type (38mm) |
| | (RU) Container Lock Double Type (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3040
013-329



- | | |
|-----------|--|
| Container | (TR) KONTEYNER KİLİT KASASI ÇİFTLİ 38 MM |
| | (EN) Container Lock Double Type (38mm) |
| | (DE) Container Lock Double Type (38mm) |
| | (FR) Container Lock Double Type (38mm) |
| | (ES) Container Lock Double Type (38mm) |
| | (PT) Container Lock Double Type (38mm) |
| | (RU) Container Lock Double Type (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3041
013-329-1



- | | |
|-----------|------------------------------------|
| Container | (TR) KONTEYNER KİLİDİ TEKLİ (38MM) |
| | (EN) Container Lock (38mm) |
| | (DE) Container Lock (38mm) |
| | (FR) Container Lock (38mm) |
| | (ES) Container Lock (38mm) |
| | (PT) Container Lock (38mm) |
| | (RU) Container Lock (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3042
013-330




- | | |
|-----------|---|
| Container | (TR) KONTEYNER KİLİT KASASI TEKLİ 38 MM |
| | (EN) Container Lock (38mm) |
| | (DE) Container Lock (38mm) |
| | (FR) Container Lock (38mm) |
| | (ES) Container Lock (38mm) |
| | (PT) Container Lock (38mm) |
| | (RU) Container Lock (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3043
013-330-5



- | | |
|-----------|----------------------------------|
| Container | (TR) KONTEYNER KİLİT MİLİ (38MM) |
| | (EN) Container Lock Pin (38mm) |
| | (DE) Container Lock Pin (38mm) |
| | (FR) Container Lock Pin (38mm) |
| | (ES) Container Lock Pin (38mm) |
| | (PT) Container Lock Pin (38mm) |
| | (RU) Container Lock Pin (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3044
013-330-1



- | | |
|-----------|------------------------------------|
| Container | (TR) KONTEYNER KİLİT SOMUNU (38MM) |
| | (EN) Container Lock Nut (38mm) |
| | (DE) Container Lock Nut (38mm) |
| | (FR) Container Lock Nut (38mm) |
| | (ES) Container Lock Nut (38mm) |
| | (PT) Container Lock Nut (38mm) |
| | (RU) Container Lock Nut (38mm) |

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3045
013-330-3



Model	Description
-------	-------------

Container	(TR) KONTEYNER KİLİT MERKEZLEYİCİSİ
	(EN) Container Lock Spare Part
	(DE) Container Lock Spare Part
	(FR) Container Lock Spare Part
	(ES) Container Lock Spare Part
	(PT) Container Lock Spare Part
	(RU) Container Lock Spare Part

Notes
x

915-3046
013-330-2



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

Container	(TR) KONTEYNER KİLİT SEKMAN 38 MM
	(EN) Container Lock Spare Part
	(DE) Container Lock Spare Part
	(FR) Container Lock Spare Part
	(ES) Container Lock Spare Part
	(PT) Container Lock Spare Part
	(RU) Container Lock Spare Part

Notes
x

915-3047
013-330-4



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

Container	(TR) KONTEYNER KİLİT MİL ve SOMUNU 38 MM
	(EN) Container Lock Spare Part
	(DE) Container Lock Spare Part
	(FR) Container Lock Spare Part
	(ES) Container Lock Spare Part
	(PT) Container Lock Spare Part
	(RU) Container Lock Spare Part

Notes
x



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3048
013-335-1

Container	(TR) KONTEYNER KİLİDİ TAMİR TAKIMI (38MM)
	(EN) Container Lock Repair Kit (38mm)
	(DE) Container Lock Repair Kit (38mm)
	(FR) Container Lock Repair Kit (38mm)
	(ES) Container Lock Repair Kit (38mm)
	(PT) Container Lock Repair Kit (38mm)
	(RU) Container Lock Repair Kit (38mm)

Notes
x



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3049
013-335

Container	(TR) KONTEYNER KİLİDİ ASANSÖR TİP DÖKÜM
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3060
013-361

Container	(TR) KONTEYNER KİLİT KASASI ARKA TİP
	(EN) Container Lock Spare Part
	(DE) Container Lock Spare Part
	(FR) Container Lock Spare Part
	(ES) Container Lock Spare Part
	(PT) Container Lock Spare Part
	(RU) Container Lock Spare Part

Notes
x



KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3061
013-361-2

Model	Description
-------	-------------

Container	<p>(TR) KONTEYNER KİLİDİ ASANSÖR KÜTÜĞÜ</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3062
013-361-3



Container	<p>(TR) KONTEYNER KİLİT MİLİ 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3063
013-361-1



Container	<p>(TR) KONTEYNER KİLİT SOMUNU 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3064
013-361-4



Container	<p>(TR) KONTEYNER KİLİT SEKMANI 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	--

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3065
013-361-5



Container	<p>(TR) KONTEYNER KİLİT TAMİR TAKIMI 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3066
013-361-6



Container	<p>(TR) KONTEYNER KİLİDİ ARKA MODEL</p> <p>(EN) Container Lock</p> <p>(DE) Container Lock</p> <p>(FR) Container Lock</p> <p>(ES) Container Lock</p> <p>(PT) Container Lock</p> <p>(RU) Container Lock</p>
-----------	---

Notes
X

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3080
013-362



Model	Description
-------	-------------

Container	<p>(TR) KONTEYNER KİLİT MİLİ UZUN 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	--

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3081
013-362-1



Container	<p>(TR) KONTEYNER KİLİT ARKA TİP SOMUNU 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	--

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3082
013-362-2



Container	<p>(TR) ONTEYNER KİLİT ARKA TİP MERKEZLEYİCİ 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3083
013-362-3



Container	<p>(TR) KONTEYNER KİLİT ARKA TİP SEKMANI 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	---

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3084
013-362-4



Container	<p>(TR) KONTEYNER KİLİT ARKA TİP TAMİR TAKIMI 52MM</p> <p>(EN) Container Lock Spare Part</p> <p>(DE) Container Lock Spare Part</p> <p>(FR) Container Lock Spare Part</p> <p>(ES) Container Lock Spare Part</p> <p>(PT) Container Lock Spare Part</p> <p>(RU) Container Lock Spare Part</p>
-----------	--

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3085
013-362-5



Container	<p>(TR) KONTEYNER KİLİDİ BORULU ASANSÖRLÜ</p> <p>(EN) Container Lock</p> <p>(DE) Container Lock</p> <p>(FR) Container Lock</p> <p>(ES) Container Lock</p> <p>(PT) Container Lock</p> <p>(RU) Container Lock</p>
-----------	---

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3100
013-359



Model	Description
-------	-------------

Container	(TR) KONTEYNER KİLİDİ ALTTAN ÇEVİRMELİ
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3120
013-364



Container	(TR) KONTEYNER KİLİDİ YATARLI MODEL
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3140
013-360



Container	(TR) KONTEYNER KİLİDİ YATIRMI TİP KİLİTLEMESİ
	(EN) Container Lock Spare Part
	(DE) Container Lock Spare Part
	(FR) Container Lock Spare Part
	(ES) Container Lock Spare Part
	(PT) Container Lock Spare Part
	(RU) Container Lock Spare Part

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3141
013-360-1



Container	(TR) KONTEYNER KİLİDİ ALTTAN KOLLU DÖKÜM
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3160
013-365



Container	(TR) KONTEYNER KİLİDİ DÖKÜM TİPİ
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3180
013-366



Container	(TR) KONTEYNER KİLİT DAR MODEL 52MM
	(EN) Container Lock
	(DE) Container Lock
	(FR) Container Lock
	(ES) Container Lock
	(PT) Container Lock
	(RU) Container Lock

Notes
x

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x

915-3200
013-367



Model

Container

Description

- TR KONTEYNER KİLİT BORULU TİP 52MM
- EN Container Lock
- DE Container Lock
- FR Container Lock
- ES Container Lock
- PT Container Lock
- RU Container Lock


Notes

x

915-3220
013-368

KONTEYNER KİLİTLERİ ve PARÇALARI / Container Lock Spare Part

DIMENSION: x



KUTLU TRUCK

www.kutlutruck.com

+90 (362) 238 11 60



info@kutlutruck.com



+90 (545) 465 55 53



+90 (546) 465 55 53

İstiklal Mahallesi Atatürk Bulvarı No:155
Tekkeköy / Samsun / Türkiye

